

PORT AUTHORITY.

Port Authority® Photo Real Snapback Trucker Cap C950

PRODUCT MEASUREMENTS

	OSFA
Crown Height	6 1/2
Width of Front Panel(s)	7 5/8
Bill/Visor Length	2 3/4

CROWN HEIGHT

Measure from middle of button at top, to brim seam along center front.

WIDTH OF FRONT PANEL(S)

Measure from side seam to side seam along bottom of crown (where bill meets crown along seam).

BILL/VISOR LENGTH

Measure from outside edge of bill to crown seam at center front.