



Eddie Bauer® Women's Soft Shell Jacket. EB531

PRODUCT MEASUREMENTS

	XS	S	M	L	XL	2XL	3XL	4XL
Chest Width	18	19	20	21 1/2	23	24 1/2	26 1/2	28 1/2
Body Length at Back	25	25 1/2	26	27	28	29	29 1/2	30
Sleeve Length from Center Back	32	32 1/2	33	33 3/4	34 1/2	35 1/4	35 3/4	36 1/4

CHEST WIDTH

Measured across the chest one inch below armhole when laid flat.

BODY LENGTH AT BACK

Measured from high point shoulder to finished hem at back.

SLEEVE LENGTH FROM CENTER BACK

Measure from Center Back neck to shoulder point to sleeve hem.