



Eddie Bauer® Women's Rain Jacket. EB551

PRODUCT MEASUREMENTS

	XS	S	M	L	XL	2XL	3XL	4XL
Chest Width	19	20	21	22 1/2	24	25 1/2	27 1/2	29 1/2
Sleeve Length	32 3/4	33 1/4	33 3/4	34 1/2	35 1/4	36	36 1/2	37
Body Length at Back	27	27 1/2	28	29	30	31	31 1/2	32

CHEST WIDTH

Measured across the chest one inch below armhole when laid flat.

SLEEVE LENGTH

Start at center of neck and measure down shoulder, down sleeve to hem.

BODY LENGTH AT BACK

Measured from high point shoulder to finished hem at back.